

Indirect Tensile Asphalt Cracking Test (IDEAL-CT)

Test Background

- Developed at the Texas Transportation Institute (TTI)
- Developed using a cylinder geometry to characterize asphalt mixture cracking resistance
- ASTM D8225-19
- Video – Test Overview
 - <https://www.youtube.com/watch?v=gXvZTE3eBNw>

Specimen Preparation

- Gyrotory Samples
 - 150 mm diameter, 62 ± 1 mm tall
 - target ± 0.5 percent air voids (7.0% air voids is common target)
- Field Cores
 - Lift thickness should be greater than 38 mm
 - 150 ± 2 mm diameter
 - If lift thickness > 62 mm, trim the top and bottom surfaces and use the middle 62 mm section
- Replicates
 - **Minimum** of three replicates
 - Recommend 4 to 5


Test Parameters

- Temperature
 - Intermediate performance grade temperature (PG IT) $\pm 0.5^{\circ}\text{C}$
 - $$PG\ IT = \frac{PG\ HT + PG\ LT}{2} + 4$$
 - If $PG\ IT > 25^{\circ}\text{C}$, use 25°C
 - Examples
 - For a project requiring performance grade (climatic temperature) of 64-28, $PG\ IT = 22$, use 22°C
 - For a project requiring performance grade (climatic temperature) of 70-22, $PG\ IT = 28$, but use 25°C

Test Parameters

- Specimen Conditioning
- 2 hours \pm 10 minutes in an environmental chamber or 30 minutes in a water bath
- Testing should be completed in 4 minutes or less after removal from conditioning


Conditioning Specimen



Test Parameters

- Test Setup
 - Specimen centered in the fixture and making uniform contact on the support
- Contact Load
 - 100 ± 10 N in Load Line Displacement (LLD) Control
- Load Rate
 - 50 ± 2.0 mm/min in LLD Control
- Test Duration
 - Typically less than 10 seconds
 - Test stopped when load drops below 100 N

Test Setup




Test Video



Specimen after Testing




IDEAL-CT Raw Data



Calculating CT_{Index}

- Work of fracture (W_f)
 - Area under the load-displacement curve
 - Unit: Joules
- Failure energy (G_f)
 - Work of fracture (W_f) divided by the cross-sectional area (product of the diameter and thickness) of the specimen
 - Unit: Joules/m²
 - $G_f = \frac{W_f}{D \times t} \times 10^6$

Calculating CT_{Index}




Post-peak slope (m_{75}) - slope of the tangent line at the 75% peak load point after the peak

Deformation tolerance (l_{75}) - displacement at 75% of the peak load after the peak

Calculating CT_{Index}

- Cracking tolerance index (CT_{Index})
 - Calculated from the parameters obtained using the load-displacement curve
 - $CT_{Index} = \frac{t}{62} \times \frac{G_f}{|m_{75}|} \times \frac{l_{75}}{D} \times 10^6$ (unitless)
 - t : specimen thickness, mm
 - G_f : fracture energy, Joules/m²
 - $|m_{75}|$: absolute value of post-peak slope m_{75} , N/m
 - l_{75} : displacement at 75% of peak load after the peak, mm
 - D : specimen diameter, mm


Data Processing Software



(NCAT Excel template available upon request)

Equipment Examples

Used for IDEAL Only




Troxler/TestQuip



Humboldt



Instrotek



Frame: Pine
Jig: Instrotek

Used for IDEAL & I-FIT

Calibration

- Have a professional service calibrate machine components annually
 1. LVDT
 - Both LLD and Actuator
 2. Load Cell
 3. Loading Rate
 - Verify rate is 50 +/- 2 mm/minute

Test Variability

- NCAT Experience – CT_{Index} Coefficient of Variation
 - within-lab COV typically about 20%
 - Use ASTM E178 to eliminate outliers

	A	B	C	D	E	F	G	H	I	J	K	L	M
1													
2	Replicates	5											
3	Significance	5%											
4													
5	Note:												
6	* Significance level represents one-sided test												
7	* If outliers can occur on either side of tail,												
8	the true significance level is 2x the input.												
9													

ASTM E178 Outlier Evaluation											
Variable	Replicate	Avg	St Dev	t-stat	E 178 crit	Outlier?					
67	1	37.94	18.36	1.583	1.671						
22	2	37.94	18.36	-0.895	1.671						
45	3	37.94	18.36	0.368	1.671						
28	4	37.94	18.36	-0.525	1.671						
28	5	37.94	18.36	-0.531	1.671						
	6										
	7										

- NCAT Round-Robin (15 labs, 1 mix) – NCAT Report 22-01
 - Between-lab COV: 35.3% when each lab fabricated specimens
 - Between-lab COV: 20.2% when one lab fabricated all specimens

Eliminate Outliers

- Each agency should have a **standardized** practice for how to deal with potential outliers
- ASTM E178 = Standard Practice for Dealing with Outlying Observations
- For each mix, calculate the average and standard deviation of the result
 - i.e. CT_{Index}

Eliminate Outliers

- Calculate the T_n statistic for the appropriate number of replicates (n)
 - Typically 4 or 5
 - $T_n = \frac{x_n - \bar{x}}{s}$
- T_c for 90% Confidence (Table 1 – ASTM E178-16a)
 - 4 replicates = 1.425
 - 5 replicates = 1.602
- If the absolute value of $T_n > T_c$ then the replicate can be considered an outlier at 90% confidence

Example of Outlier Analysis

- Average $CT_{Index} = 72.6$
- Standard Deviation = 10.5
- $T_c = 1.671$
- Replicate 1: $CT_{Index} = 75 - T_n = 0.229$
- Replicate 2: $CT_{Index} = 81 - T_n = 0.800$
- Replicate 3: $CT_{Index} = 80 - T_n = 0.705$
- Replicate 4: $CT_{Index} = 55 - T_n = -1.676$ (Outlier)
- Replicate 5: $CT_{Index} = 72 - T_n = -0.057$

Example of Outlier Analysis

- Before Outlier Removal
 - Average = 72.6
 - Standard Deviation = 10.5
 - COV (%) = 14.4%
- After Outlier Removal
 - Average = 77.0
 - Standard Deviation = 4.2
 - COV (%) = 5.5%

Outlier Evaluation

- Technician notes regarding a particular sample may also create outliers
 - Something may have gone wrong during fabrication or testing
- A statistical outlier may not be a practical outlier
 - Always look at the raw data
 - Example: Try 108, 109, 104, 111, 102, 90


Advantages – IDEAL-CT

- Specimen Fabrication is straightforward
 - No sawing required
 - Disclaimer: Straightforward \neq Impossible to Mess Up
- Relatively low cost performance testing equipment
- Test is quick to perform
- Training is straight-forward
 - Specimen preparation standardization is recommended
 - CT_{Index} is sensitive to sample fabrication (reheating and conditioning procedures)

Limitations

- Effect of density
 - Trend of increased CT_{Index} with higher specimen air voids observed in several studies
 - Agencies should standardize specimen air void content

Additional Insights



The CT_{Index} Interaction Diagram may be helpful in understanding the effects of many common mix variables.

Questions?

— randy.west@auburn.edu —